






AT-Link USB






AT-Link power supply



LD1-4:For AT-Link-EZ status


AT-Link MCU




TITLE: AT-Link-EZ		REV: 1.2
	Company: Artery Technology	Sheet: 1
	Date: 2021-12-20	Drawn By:




MCU power supply



Crystal




Boot & Reset




MCU


TITLE: MCU	REV: 1.0
Company: Artery Technology	Sheet: 2
Date: 2021-12-20	Drawn By:




AT-START power supply




OTG1_host




User key




USART1 / OTG1 selection




OTG1




AT-Link connector



LED




USART1 for ISP





Test points

TITLE: Power & Peripherals		REV: 1.0
	Company: Artery Technology	Sheet: 3
	Date: 2021-12-20	Drawn By:



Close to MCU



Arduino UNO R3 connectors

TITLE:	Extension connector	REV: 1.0
Company:	Artery Technology	Sheet: 4
Date:	2021-12-20	Drawn By: